

Fault Trapper™

Transient Fault Location for Energized Dedicated Circuit Breakers



TFT100 User Manual



Toll Free: 800-749-5783
www.platinumtools.com



This product should only be used by and connected/disconnected from a circuit to be tested by qualified service personnel or certified electricians

Introduction

Fault Trapper™ is a new class of tester intended to locate the distance to a circuit anomaly that is either intermittently causing a change in the circuit's characteristics or blowing the circuit breaker.

Fault Trapper™ can capture and save up to two events (open and/or short) per test session and save them separately. If the circuit breaker trips, the backup battery powers the Fault Trapper™ to allow for an orderly shutdown. The last faults can be viewed using the battery power. An In-Line Adapter is used to isolate the circuit being monitored from the breaker panel and all other breakers.

Key Features

- Unattended in-line monitoring of energized dedicated circuits up to 300 VAC and 40 amps
- Fault Location reported as distance from Fault Trapper™
- Detects a fault whether or not it trips the circuit breaker
- Timer logs elapsed time of tests
- Back-up battery allows capture of breaker trips/Unpowered display of results



Safety Alert Symbols	Definition
	Warning: Potential for personal injury Caution: Potential for damage to or destruction of equipment
	Conformité Européenne. Conforms to European Economic Area directives.
	Disposal Information
	Warning: Electricity - High Voltage
	Warning: Hot Surface

Safety Information

To ensure safe operation of the Fault Trapper™, follow instructions carefully when using the unit and observe warning and caution messages listed in this manual. Failure to observe warnings can result in severe injury or death and can damage the unit.

- Fault Trapper™ is for use only by persons qualified to work in and around breaker panels.
- Do not use the Fault Trapper™ or cables if they appear damaged or the unit is not working properly.
- Do not use with voltages and currents higher than what the Fault Trapper™ is rated for. The Fault Trapper is rated for 110/120VAC to 230/240VAC branch circuits at a maximum of 40 amps.
- Turn off circuit breaker prior to attaching Fault Trapper™ and in-line adapter to circuit to be monitored.
- Do not use around explosive or flammable gas.
- Use only test leads provided for connecting the Fault Trapper™ to the 40A In-Line Adapter Module.
- Before opening the battery door, remove cables from Fault Trapper™.
- Always wear personal protective equipment when working with the Fault Trapper™
- Do not open case of either the Fault Trapper or the In-Line Adapter (when changing the fuse) with any cables connected to it.


Contents:



Fault Trapper
Main Unit



40 Amp In-Line
Adapter



Two Plug-in 2-Wire
Terminal Block
Connectors - 8 to 24
AWG (0.2 to 10 mm)



Banana Plug Leader Cable



Contents (cont.):

- Duracell® 9 Volt Alkaline Battery. (Note - Do not use "Heavy Duty" Carbon batteries or generic budget batteries.)
- User Instruction Sheet
- Warranty Card

Orderable Accessories and Replacement Parts:

Part Number	Description
6075	Spare Plug-in 2-Wire Terminal Blocks (Set of 2)
6076	Replacement Banana Plug Leader Cable
19202	Insulated 1/8" Screwdriver (1000V Rated)
TCA008	Hanging Strap with Carabineer


Fault Trapper™ Front Panel and Connections:



1. Load Terminal Jack (L1/L2)
2. Source Terminal Jack (S1/S2)
3. Banana Plug Leader Cable Jacks
4. Backlit LCD Display
5. Display Button (View Faults)
6. Ignore Button
7. Test Button (Start/Stop Monitoring)
8. Distance Buttons (Press & Hold to change to Feet or Meters)

Front Panel and Connections (Cont.):

- 1. Load Terminal Jack (L1/L2)** - Wire or wires removed from load attaches here using supplied Plug-in Terminal Block Connectors
- 2. Power Source Terminal Jack (S1/S2)** - Usually attached to circuit breaker terminal or terminals, using the supplied plug-in terminal blocks. Screw on terminal block should be tightened to 7 in/lbs.
- 3. Banana Plug Leader Cable Jacks** - Supplied Banana Plug Leader Cable connects 40A In-Line Adapter Module to Fault Trapper™.
- 4. Backlit LCD Display** - Shows Distance to Fault, Elapsed Time to Fault, Fault Type (Short/Open), and Battery Status
- 5. Display Button** - Used to power unit on briefly to view faults when not powered by AC and to toggle between a breaker trip fault and a non-breaker trip fault, if there is one.



Displayed	Elapsed Time of Test
59.9	<i>From the first 0.1 min to 59.9 mins:</i> The elapsed time will be displayed in minutes and tenths of a minute (0.1 equals 6 seconds)
23h	<i>From the first hour until 23 hours:</i> The elapsed time will be displayed as hours (1h to 23h)
99d	<i>From the first day until the 99th day:</i> The elapsed time will be displayed as time in days (1d to 99d)

6. **Ignore Button** - Press to ignore events that are part of the circuit's normal operation.
7. **Test Button** - Press Button to start a monitoring session. Press during a monitoring session to stop a test if running.
8. **Distance/Units Button** - Press and hold the Display and Ignore buttons for 3 seconds. The "ft" or "m" icons will flash denoting the new unit used for measurement.
9. **Terminal Block Connectors** - Insert the circuit wires or jumpers into these blocks and insert the blocks into the designated jacks. To remove the Terminal Block Connectors:
 - a.) push and hold the orange side tabs towards the jack
 - b.) then pull the block connector out.

⑨

a) Push and Hold



b) Pull to remove




Details and Functions of the Fault Trapper™ 40A In-Line Adapter Module



Caution - Turn off power to the circuit the In-Line Adapter is being connected to!

The Fault Trapper measures the wired pair impedance in the circuit to sense an electrical event as a fault. The 40A In-line Adapter Module is positioned between the Power Source and the Load at the breaker. Power for Main Unit is tapped off a coil in the 40A In-line Adapter Module through a fuse (Littelfuse® p/n 0215.250) via the Banana Plug Leader Cable.





40A In-Line Adapter Module Connections

VOLTAGE	LOAD (WIRING TO LOAD)		SOURCE (CIRCUIT BREAKER)	
	L1	L2	S1	S2
110/120 VAC	BLACK	WHITE	BLACK	NO CONNECTION
230/240 VAC	BLACK	RED	BLACK	RED
GFI/AFCI	BLACK	WHITE	BLACK	WHITE

Note! Use only on Energized Dedicated Circuits, Max 40 Amps.




Caution - Turn off power to the circuit the In-Line Adapter is being connected to!

Connecting the Fault Trapper 40A In-Line Adapter Module to Circuit Breakers (USA)

To connect to a 120VAC Standard Breaker (up to 40 Amps)

All connections to the Fault Trapper 40A In-Line Adapter Module are made using plug-in terminal block connectors; torque screws to 7in-lbs:

1. Noting the alignment of the Terminal Block Connector relative to the Load Terminal Jack on the 40A In-Line Adapter Module, remove the hot wire from the breaker being tested and insert it into the Terminal Block Connector so that it is matched with Load Terminal “L1”. Torque down the fastening screw to 7 in-lbs.
2. Strip the ends off a white jumper wire and connect one end to the neutral/ground bus bar and insert the other end into the Load Terminal Block Connector so that it is matched with Terminal “L2”. Torque down the fastening screw to 7 in-lbs.




120VAC Connection Diagram

3. Insert the Load Terminal Block Connector into the Load Terminal Jack until it is seated firmly and lock tabs are fully engaged.
4. Strip the ends of another jumper wire and connect one end to the Circuit Breaker (where the wire was removed in Step 1) and the other end to the Source Terminal Block Connector so that it is matched with Source Terminal “S1”.
5. Connect the Fault Trapper meter to the module using the included Banana Plug Leader Cable.

To connect to 220VAC Standard Breaker (up to 40amps):

All connections to the Fault Trapper 40A In-Line Adapter Module are made using supplied Plug-in Terminal Blocks Connectors, torque screws to 7in-lbs:




1. Remove the two hot wires from the breakers for the load being tested and attach them to the Load side of the Fault Trapper 40A In-Line Adapter Module with the black in Load Terminal “L1” and the red wire in Load Terminal “L2” using the Plug-in Terminal Block Connector.
2. Strip the ends of a black jumper wire and connect one end of the wire using the Source Terminal Block Connector Source at Source Terminal “S1” and the other end to the breaker terminal where the black wire was removed from in Step 1.
3. Strip the ends of a red jumper wire and connect one end of the wire to the Source Terminal Block Connector at “S2” and the other end to the breaker terminal where the red wire was removed from in Step 1.
4. Insert the Load Terminal Block Connector into the Load Terminal Jack until it is seated firmly and lock tabs are fully engaged.
5. Connect the Fault Trapper meter to the module using the included Banana Plug Leader Cable.

To connect to a 120VAC GFI or AFCI breaker (up to 40amps):

All connections to the Fault Trapper 40A In-Line Adapter Module are made using supplied Plug-in Terminal Blocks Connectors, torque screws to 7in-lbs:

1. Remove the hot and neutral from the breaker and attach them to the load side of the Fault Trapper 40Amp Adapter Module with the black wire at "L1" and white neutral at "L2".
2. Keep the curly pigtail neutral white wire from the GFI/AFCI breaker connected to the Neutral/GND Bus bar.
3. Connect a black jumper wire from the HOT port of the GFI/AFCI breaker to the Source Terminal "S1"
4. Connect a white jumper wire from the NEUTRAL port of the GFI/AFCI breaker to the Source Terminal "S2" and connect the Fault Trapper meter to the module using the included Banana Plug Leader Cable.



Instructions for Use

After connecting in one of the configurations above and switching on the breaker(s).

1. **Powering on Unit** – Once the unit is powered by the AC power connection the battery level will be shown on the display. The unit will be ready at this point to run a test.

If there is no AC power connection the Display button can be used to power the unit on using battery power to show the results from a previous test.



Power On, No Prior Screen.

2. Starting a Test

– While powered by the AC power connection press the Test button. The Fault Trapper will not run a test under battery power. The velocity of propagation used for distance measurement is 70% the speed of light, a nominal value for power wiring, and is not configurable.

Before you start, note the time.

The Fault Trapper displays the elapsed time from when you start the monitoring to when the fault occurs. You will need to know the starting time to determine when the fault occurred.

3. **Test Running** – When a test is started “zero’s” will be scrolling left to right in the test results area and the up down arrows on the left side will be flashing until a fault is shown.

Once a fault is found the up down arrows will continue to flash while the test is running while the distance to the last fault found is shown.

The lower left portion of the screen denotes the time. Before a fault is found the time will show how long it has been since the test started. Once a fault is found the last fault will be shown and the time will show how long the time was between the beginning of the test and the last fault found.



Press to start monitoring session.



Testing for 2.9 min, no faults

4. **Stopping a Test** – The three ways a test can stop are:

- a. When the AC power goes down,
- b. The Test button is pressed
- c. The Ignore button is pressed.

When the AC power goes down the unit will run on battery power for long enough to finish scanning for the fault which may have caused the AC to power off (breaker trip). If a fault occurred within the last several seconds before the AC went down it will be classified as the “Breaker Trip Fault”, the “Voltage!” icon will be displayed when this occurs.


A non-breaker trip fault (if found earlier during the test) will also be saved. When the Test button is pressed during a test any fault found will be saved as a “Non-Breaker Trip Fault” and testing halted. A second press of the Test button will restart testing.


5. Ignore Feature – The ignore function allows for ignoring a fault location that is being reported under normal operation of the circuit. The primary use would be when a load which causes “faults” during testing that are not important and should be ignored to make it easier to find real wiring issues. One example would be an air conditioning compressor cycling on and off.

A fault that trips the breaker will be shown in the results regardless of whether or not the fault was ignored.

Setting an Ignore - To save an ignore location press the Ignore Button for a short time. When an ignore is set the

Fault Trapper will alternate showing the distance to be ignored and “IGN” until testing is resumed. If the Ignore Button is pressed while a test is running the test will be stopped and the last fault found will be saved. If the test is not running the fault to be ignored must be chosen using the Display Button to toggle to the fault to be ignored and then a short press of the Ignore Button will save that location. The ignored location will continue through power cycles of the







Fault Trapper. When powered on with AC power the ignore location will be shown on the screen and “IGN” will be displayed in the lower left corner of the screen.

Clearing an Ignore – To clear an ignore location press and hold the Ignore Button until “CLR” is displayed on the screen.




6. **Test Results** - The Display button is used to show test results. If the AC power connection is off the unit will use the 9 volt battery to power on the display and show the results from the last test. There can be a “Breaker Trip” fault and a “Non-Breaker Trip” fault. The voltage icon will flash indicating that the fault shown caused the breaker to trip. Tap the Display button to cycle between the two faults (if there are more than one). Ft and M units can be toggled by holding down the Display and Ignore buttons for 3 seconds.





Displaying Results using DISPLAY Button



Testing Stopped with No Results

7. **Battery Remaining** – In the lower right portion of the screen is a battery icon with bars showing how much remains for the 9V battery. Three bars shows a full battery, two bars is between 33% and 66%, one bar is between 33% and 10%. A flashing battery outline icon shows that there is less than 10% battery life remaining.

Since the test runs for a short time after the AC power shuts off it is recommended to replace the 9V battery (with no AC power present) once the battery indicator shows one bar or a flashing battery outline icon.

Maintenance

Changing the Battery



Warning! Remove any cables attached to the Fault Trapper™ before opening any battery compartment!

1. Remove screw on rear of unit near the middle with a #1 Philips head screwdriver.
2. Remove battery and disconnect from battery snaps.
3. Attach a new 9 volt alkaline battery to the battery snaps and return to battery compartment.
4. Place battery cover in slot and rotate shut. Fasten shut with screw removed. Do not over tighten!

Replacing the Fuse in the 40A In-Line Adapter Module

The 40A In-Line Adapter Module contains a fuse used to protect Fault Trapper cabling and circuitry.



Warning! To avoid electrical shock, remove any cables attached to the 40A In-Line Adapter Module before opening the case!

Replace fuse with same type and rating! The fuse is a special type capable of interrupting high current circuits.

1. Remove four case screws using a T-15 Torx® driver and open the case.
2. Remove Fuse cover and fuse. Replacement fuse is Littelfuse® p/n 0215.250, 5x20 mm, time-lag, 0.25Amp, 250VAC.
3. Replace fuse cover, reassemble case, replace 4 screws and tighten.



Warning! Never operate 40A In-Line Adapter Module without the connector side panel being installed! After servicing the fuse, verify safe state of case and operation of unit.

Specifications

Physical Dimensions

Fault Trapper Main Unit

Size: 15.25 x 7.6 x 3.8 cm (6.0 x 3.0 x 1.5 inches)

Weight: 255 grams (9 oz.) with battery

40A In-Line Adapter Module

Size: 11.5 x 7.6 x 5.85 cm (4.5 x 3.0 x 2.3 inches)

Weight: 312 grams (11 oz.)

Input Rating:

Fault Trapper Main Unit: 90 to 265 Volts AC RMS 50/60 Hz,
4 Watts max.

40 Amp In-Line Adapter: 300 Volts AC RMS, 40 Amp circuits
maximum, supplies power to main unit

Measurement Method: Spread Spectrum Time Domain Reflectometry (SSTDR)

Accuracy: +/-10% of reading

Maximum Length: 300 ft on NM-B or Wire in Conduit

Battery is used to review results when not AC powered

Battery Low Level: Approximately 5.5 volts

Battery Life (9 Volt Alkaline battery, typical)

Standby: 2 years

Active: 4 hours typical

Environmental

Temperature

Operating: 0° to 50°C (32° to 122°F)

Storage temperature: -20° to 60°C (-4° to 140°F)

Long Term Storage w/ battery: 35°C maximum (95°F)

Humidity: 10% to 90%, Non-Condensing

Altitude: 2,000 meters (6,561ft) maximum

Patents / Intellectual Property

Platinum Tools product: Fault Trapper may be covered by one or more of the following patents: US Patent No. 6868357, US Patent No. 6937944, US Patent No. 7069163, US Patent No. 7215126, US Patent No. 7250772, US Patent No. 7271596, US Patent No. 7165200, US Patent No. 7495450, US Patent No. 7075309, US Patent No. 7282922, US Patent No. 7634012, US Patent No. 7622931, US Patent No. 7548071.

Fault Trapper™ FAQ

Does the Fault Trapper Require Batteries?

- Yes, the Fault Trapper requires a 9V battery in the event of Power Loss from the wires under test. The Fault Trapper requires a high quality welded cell 9V battery such as Duracell®. Generic budget batteries may not be sufficient to power the Fault Trapper.

The Fault Trapper main unit does not power up when it is connected to AC power.

- Check that the Fault Trapper is connected correctly.
- Check the fuse in the 40A Adapter Module. If the fuse is blown, a replacement can be ordered from Digi-Key® at www.digikey.com, P/N F4603-ND.

The Fault Trapper does not see a fault when I short the wires to trip the breaker intentionally.

- If the ignore button has been pressed, the Fault Trapper will ignore the fault. Press and hold the Ignore button until the LCD displays “clr”, this clears the ignore feature.

Does the Fault Trapper and 40 Amp Adapter Module work in wet environments?

- No, the Fault Trapper and 40 Amp Adapter module must be operated in dry environments.

Can I use my own longer or shorter Banana Jack leader cable between the Isolation module and main unit?

- No. The impedance, length and voltage rating is critical to safe and correct operation of the unit.

My unit seems to work fine, but doesn't save the last event detected.

- The battery must have enough energy to run the unit for 5 seconds on battery power alone. If your battery is low or poor quality, the unit may not be powered on long enough to save the results.

The Fault Trapper doesn't report the breaker tripping because of sustained over-current loads; I thought it would tell me where the fault is.

- The Fault Trapper does not measure current. The Fault Trapper is designed to locate actual wiring faults. If the over-current event is

from a wiring short (not just the load at the end of the run) it will be detected as a short at the event distance.

How can I get the latest information on my Fault Trapper?

- Go to www.platinumtools.com for manual updates, more FAQs, and other important information.

Will the Fault Trapper detect series and or Parallel arc faults?

- It depends on the nature of the connection/parallel arc event. When the Fault Trapper detects an open or loose wire connection for 5 half AC cycles in a row (33mS) it will be reported as an open fault. Parallel arc detection takes 5 half AC cycles with low impedance to be detected as a short fault. In the case of parallel arcing, if the shorting material is blown out, blown apart, vaporized or somehow removed before the 5 half cycles, it may not be detected as a fault.

How far down a daisy-chained branch circuit would the Fault Trapper be able to detect faults?

- The Fault Trapper is optimized for monitoring homerun circuits. Using it to monitor circuits that extend beyond a homerun may detect a fault but the accuracy of displayed distance to the fault maybe affected.

Sometimes the circuit breakers are due to ground faults, will the Fault Trapper detect this?

- The Fault Trapper is capable of detecting electrical events due to shorts and opens between hot and neutral lines. It will not detect events due to ground-faults.

Most circuits in a breaker box use dedicated neutrals for each line, however, there are cases where two hot wires may share a common neutral. Would this compromise the Fault Trappers ability to detect a fault?

- The two hot wires have to be different phases, effectively a 240V line using 120V to the neutral from each phase instead of using the 240 available across the two hot wires. This should not be a problem for Fault Trapper. Connect Fault Trapper to Hot line to be monitored and the neutral bus as shown in 120V hook up section.

Snap Shot™ Cable Fault Finder



Platinum Tools recommends the Snap Shot™ Cable Fault Finder for a great companion tool with your Fault Trapper!

With the Fault Trapper you are able to find the approximate location of a fault in a dedicated circuit. To find the length to the fault to within 1% accuracy or better you need a cable fault locator time domain reflectometer tool that is fast, accurate and easy to use to see down the wire and show the exact conditions that exist. The Snap Shot™ is that tool.

The Snap Shot™ accurately finds cable length, impediments in the cable and conditions at the end of every wire in your data, power, or communications/video system up to 3,000 ft. Calibrate it for your specific cable for the most accurate length measurements available.

Advanced Spread Spectrum TDR technology works in all wire environments and is immune to voltage, current, or data stream disruptions. See the true picture of your wiring and cable systems with the Snap Shot™ cable fault detector and length measurement tool today.

Notes



Toll Free: 800-749-5783
www.platinumtools.com