

Attach the clear clips to the acrylic panels to your desired locations.

1. Set the acrylic assembly on top of the work surface and position it to your desired location.  
\*Don't peel the backing off yet
2. Mark the locations of the clear clips with a pencil or marker on the work surface.
3. After you marked the locations then take the assembly off the work surface and remove the clear clips.
4. Remove the backing off of the strip of tape.
5. Attach the clear clips to the work surface where you made the marks.
6. Press down on the clips to secure it to the work surface.
7. Carefully slide the acrylic panels down into the clear clips.

Note:

The acrylic panels must be rigidly or mechanically connect to another panel.  
Panels can not be free standing.



