

INSTALLATION INSTRUCTIONS

FLS0005 - Pilot Burner Assembly



WARNING
Disconnect power before
servicing equipment.

1. **Turn the furnace power off and gas.**
2. Remove screws that hold the pilot assembly mount to the burners.
3. Unscrew pilot tubing nut on gas valve and then lift entire pilot assembly out. Pull high voltage lead out of the electrode.
4. Unscrew the pilot tubing nut on pilot assembly end and remove.
5. Take the new 3 wire pilot and either mount the old electrode in it or if you've purchased a new electrode, slide that on and tighten single screw.
6. Screw pilot tubing nut back on the new pilot and tighten.
7. Put the high voltage lead back on the electrode and remount the pilot assembly with the 2 screws taken out earlier.
8. Tighten the pilot tubing back on the gas valve and hook up the wiring harness.
9. Turn on furnace power and gas.
10. Test to make sure pilot is lighting properly.

800.333.9125 - techsupport@supco.com - www.supco.com