

SHOCK KIT - LP5917

Can Replace 5304485917

Kit includes the following parts:

- (2) Shock Absorbers
- (1) Spare Shock Mounting Pin
- (4) Nuts

1. To remove old shocks, use a small flat screwdriver to depress the pin lock tab. Use a plier to remove the pin from the mounting hole.
2. Remove the old shock absorbers.

Keep the pins.

3. Install new shock absorber with plunger shaft toward the cabinet base and the plastic housing toward the tub.
4. Fully insert the mounting pins. Use extra mounting pin if needed.
5. Reconnect power and run through spin cycle to test.

800.333.9125 - techsupport@supco.com - www.supco.com



Disconnect power before servicing equipment.

