

CLASSIC PATCH KIT INSTRUCTIONS

PROPER USE:

- Lightly buff area around puncture with metal scuffer, removing loose particles. Make sure the entire area within ½in. (13mm) of puncture has roughened appearance.
- Squeeze moderate amount of rubber cement onto roughened surface and spread evenly. Work into material and scrape off excess.
- Remove backing from patch without touching exposed surface.
- Apply patch directly over puncture and press firmly around the edges.