
## **HOW TO USE**



Scuff tube hole area, wipe clean and dry.



Peel off back of patch, stick patch over hole and press hard to smooth out wrinkles.