



DRAWER INSTALLATION INSTRUCTIONS



Locate the correct eight (8) black dots for the product code you are installing.



The front edge of the paper represents the front edge of the worksurface. The dashed line represents the center of the drawer. Align the front edge of paper with the front of the worksurface and the dashed line with the center of the drawer location. Tape the template to the bottom or underside of the worksurface.



Inspect the worksurface to be sure the screws provided will not go through to the top of worksurface. Using a 5/64" drill bit, bore 1/2" deep starter holes through the correct eight (8) black dots on the template.



Extend the drawer to its locked open position and install with the screws provided. Do not tighten screws. Slide drawer to the locked closed position to ensure alignment of rails. Tighten rear screws completely. Extend drawer to its locked open position once again and tighten front screws completely. Be sure to install all eight (8) screws to ensure the unit works properly.

