

SGF-DA20B

INSTALLATION INSTRUCTIONS

1. Shut off the main water supply valve to the refrigerator
2. Remove old cartridge by grasping firmly and twisting counterclockwise 1/4 turn
3. Push new filter into the filter receiver and turn 1/4 turn clockwise until it locks
4. Turn on the main water supply valve to the refrigerator
5. Flush the refrigerator water system after replacing the water filter cartridge. Sputtering may occur until air is purged from water line and filter
6. Reset water filter status display - replace the filter every 6 months