

NEBO[®]
SOLAR ZAPPER & LANTERN



NEB-ZAP-0003

QUALITY GUARANTEE

This product is guaranteed against all defects in workmanship and materials for the original owner for one year from the date of purchase. Damage to or failure of the product or any component thereof due to alteration, misuse, or lack of maintenance will void warranty and all guarantees.

DATE OF PURCHASE: _____ PRODUCT SKU: NEB-ZAP-0003

Contact 800.255.6061 for product questions, assistance or warranty claims.

Register your warranty at:

WWW.NEBOLIGHTS.COM



FOR OTHER GREAT PRODUCTS, VISIT
WWW.NEBOLIGHTS.COM

SOLAR ZAPPER & LANTERN

The Solar Zapper & Lantern combines warm LED lighting with a bug-zapping grid to help control mosquitoes and other flying insects. With an automatic on/off feature, the zapper turns off in daylight to allow for charging by solar panels. The Zapper features three modes for use at night; Warm LED Light, Zapper or Warm LED and Zapper together.

FEATURES:

- Dual Band UV Technology*
- Solar-powered
- Automatic On/Off feature
- Rubbery carrying handle
- Water-resistant
- Elegant and rugged

* Patent Pending



OPERATION

To operate, twist the top of the Zapper Latern to choose your desired mode indicated by the icons.

- Off
- 🔥 Warm LED Light
- 🔌 Zapper
- 🔥🔌 Warm LED Light and Zapper



CHARGING

To charge, plug the included USB-C cable into a power source and the other end into the zapper's charging port. The zapper features a charge indicator light above the USB charging port.

While In Use

Solid Red = 20% Charge Remaining

Flashing Red = 10% Charge Remaining

While Charging


Solid Red = Charging

Solid Green = Fully Charged

Charge Times

USB Cable = 3 Hours

Solar Panels = 18 Hours in full sunlight.



MAINTENANCE

Make sure that the Solar Zapper is OFF and wait five minutes before performing any maintenance or cleaning.

Do not use spray cleaners on the Solar Zapper.

Dispose of any insects inside the zapper. To clean, remove the base of the Zapper by twisting the base clock-wise. Clean any bugs or dust out of the base with the included brush, then twist the base back onto the Zapper.



CAUTION

- Keep out of reach of children.
- Do not insert fingers or other objects into the zap grid.
- Do not clean with water spray or other liquids. Use a damp or dry cloth to clean.
- Empty trap and dispose of the zapped insects frequently.
- Battery is not replaceable.
- Use only as directed.

RUBBER
CARRYING
HANDLE

SOLAR
PANELS

MODE
SELECTION
DIAL

WARM
LED LIGHT

USB-C
RECHARGEABLE

POWERFUL
1300 VOLT
ZAPPING GRID

DURABLE
CONSTRUCTION

DUAL-BAND
UV LIGHT
(Patent Pending)

REMOVEABLE
BASE



CLEANING
BRUSH
INCLUDED

