

# NEBO®

## BIG LARRY™



### BIG LARRY™

Powered by 3 AA batteries, the Big Larry features a 220 lumen Flashlight, 600 lumen COB Work Light and a 40 lumen Red COB Work Light.

MODES	LUMENS	RUN TIME	METERS
FLASHLIGHT HIGH	220	4.5h	82
FLASHLIGHT LOW	60	24h	50
WORK LIGHT HIGH	600	2.5h	33
WORK LIGHT LOW	150	14.5h	18
RED HIGH	40	20h	7
RED LOW	12	32h	1
RED STROBE	40	40h	7

### PRODUCT GUARANTEE

If you experience a problem, please do not return to your local store. Contact our Customer Service team at **800-255-6061** or [www.nebotools.com/contact](http://www.nebotools.com/contact)



For more information, detailed video instructions, and warranty registration, visit [NEBOTOOLS.com](http://NEBOTOOLS.com).

### DISABLE DEMO MODE

Product is shipped with Demo Mode active. Before normal use, you will need to deactivate Demo Mode.

To deactivate, simply remove the three alkaline batteries from the work light for at least 10s. This will deactivate Demo Mode.

### OPERATION

Press & release Power Button to cycle through light modes:  
**Spotlight 100% > Work light 100% > Red Work light 100% > Red Strobe**

**Direct-to-Red:** From OFF, press and hold Power Button for two seconds.

If no Press & Release activity for greater than 8 seconds, then next button push always turns OFF unit. The Press & Hold function will ignore this 8 second timeout feature so that the light can be dimmed at any time.


### DIMMING

From On, Press & Hold the Power Button.

### MEMORY

This unit will automatically save your last used Dimming settings.

To recall your last used settings, Press & Release the Power Button twice within one second.



### BATTERY

This unit is powered by 3x AA batteries. To replace batteries, unscrew the base and insert batteries positive (+) side first.

Do not mix old and new batteries. Do not mix alkaline, standard (Carbon-zinc), or rechargeable (Ni-Cd, Ni-Mh, etc) batteries.

