



FLEX-POWER

Flex-Power allows this unit to run on the included rechargeable battery or disposable alkaline batteries.

RECHARGEABLE

Use the included charging cable to recharge the unit. Power button will indicate battery level.

POWER INDICATOR

Off: Battery more than 25% Flashing Red: Battery less than 25%

CHARGING INDICATOR

Red: Battery charging Blue: Battery fully charged



Press & release power button to turn the unit off and on and cycle through light modes:

OPERATION

High > Low > Off

Strobe: Double-tap button


press will turn the unit off.

not available when using AA alkaline batteries).

When light is ON for 8 seconds or longer, the next button

Turbo: From ON, press and hold power button (Turbo mode is





BATTERY

standard AA battery.

PRODUCT GUARANTEE



If you experience a problem, please do not return to your local store. Contact our Customer Service team at 800-255-6061 or www.nebolights.com/contact

For more information, detailed video instructions, and warranty registration, visit **NEBOLIGHTS.com**