## INSTALLATION INSTRUCTIONS

## STC5257--THERMAL CUTOUT 15 AMP, 257°F

Rated for continuous operating currents up to 10 amps @ 250VAC/15 amps @ 120VAC, or 5 amps @ 24VDC

Designed for over-temperature protection.



Disconnect power before servicing equipment.

1. Disconnect power.

- 2. Remove screw holding ceramic body. (Keep screw)
- 3. Remove wires from thermal cut out.
- 4. Before installing new thermal cutout, check to ensure the wire connectors are not damaged or loose.
- 5. Reconnect wires to the thermal cutout.
- 6. Attach ceramic body with screw.
- 7. Reconnect power.

800.333.9125 - techsupport@supco.com - www.supco.com