



### What's Included

Pushable Fiber Cable

Metal "Bullet" Dust Cap

White Inner SC Housing

Green Outer SC Housing






### Push/Pull




Note: Pull-loop on "Bullet" cap may be used for pulling extended distances through a wall or ducted pathway

### Pushable Fiber Assembly Instructions



1. Use both hands to hold the black boot and metal cap (be careful not to touch the ferrule end face). Unscrew the metal "bullet" cap.



2. Set metal cap aside



3. Align the white inner housing key with the metal boot. Push the white inner housing down onto the metal boot until it snaps into place.





## Pushable Fiber Assembly Instructions (cont.)

Cut-out of white inner housing




Metal boot cut-out faces the cut-out of white inner housing

4. Align the white inner housing with the green outer housing and snap the green outer housing into the white inner housing.



Rounded edge



5. Finished fiber assembly

