


NEBO®

TORCHY™ 3K



CHARGING

Insert one end of the charging cable into the charging port on the light and the other end into a power source.



CHARGING STATUS

When plugged in, the power button serves as the charging status indicator

- Pulsing Green: Charging
- Solid Green: Charged completely

POWER INDICATOR

When in use, the power button acts as a power indicator.

- Solid Orange: Battery > 25%
- Flashing Orange: Battery < 25%

OPERATION

Press the power button repeatedly to cycle through light modes:
HIGH > MEDIUM > LOW > OFF

TURBO: Press and hold power button from ON. After 30 seconds or if the button is released, the light will return to the previous mode.

DEFENSIVE STROBE: Double press the power button.

DIRECT-TO-LOW: Press and hold power button from OFF. If the button is pressed again within 8 seconds of activation, the above mode cycle is reversed.

LOCKOUT: triple press the power button from OFF to toggle LOCKOUT ON and OFF.

MODES	OUTPUT (Lumens)	RUN TIME (Hours)	BEAM DISTANCE (Meters)
TURBO	3000	30s*	150
HIGH	800	2h	80
MEDIUM	250	3.5h	40
LOW	50	20h	20
STROBE	✓	✓	✓

PRODUCT GUARANTEE



If you experience a problem, please do not return to your local store. Contact our Customer Service team at 800-255-6061 or NEBOLIGHTS.com

For more information, detailed video instructions, and warranty registration, visit NEBOLIGHTS.com