


NEBO[®]

REDLINE[®]X[™]

LIGHTING INSTRUCTIONS

The REDLINE X has Switch X Technology, which uses a patented paddle switching mechanism for easy light activation and mode control.

POWER BUTTON



MODE BUTTON

Press the Power Button to turn the light on (light will activate in the last used mode). Press and hold Power Button from OFF to momentarily activate the last used mode.

While the light is ON, press the Mode Button to alternate between HIGH and LOW mode.

From the ON or OFF position, double-tap the Mode Button to activate Variable Strobe Mode.

From the ON or OFF position, press and hold Mode Button to activate Turbo Mode (Turbo Mode operates on momentary activation; light will turn OFF or return to the previous mode when button is released).

CHARGING INSTRUCTIONS

Charge with included cable.

A **RED** indicator light will turn ON while charging.

Light will turn **GREEN** when fully charged. Charging will take up to 3 hours.



4x ZOOM



FLOOD
LIGHT

SPOT
LIGHT

The REDLINE X has an adjustable 4x zoom to change from spot light to flood light.

Turn the head clockwise for flood light.

Turn the head counter-clockwise for spot light.

Register for warranty
www.NEBOTools.com

All copyrighted and copyrightable materials, including, without limitation, the logo, design, text, graphics, pictures, copywriting, and the selection and arrangement ("Materials") thereof are ALL RIGHTS RESERVED. Copyright ©2023 Alliance Sports Group L.P.