

INSTALLATION INSTRUCTIONS

Th181975 - THERMOCOUPLE 39”

Note: This is a metric thread thermocouple designed to fit York and Nordyne units



Disconnect power before servicing equipment.

1. Turn the furnace power off and gas.
2. Remove existing thermocouple.
3. Replace with new thermocouple.
4. Turn on furnace power and gas.
5. Test to make sure furnace is working properly.

800.333.9125 - techsupport@supco.com - www.supco.com