BATTERY PACK






Add the battery pack to any of our U.S. made height adjustable products to become cord-free.

- Battery lasts up to 200 cycles on a single charge (about 2 3 months of regular use, can last longer with less frequent use)
- Includes a charger (plugs into the wall and has a cord)
- LED lights on the battery pack indicate the level of charge
- The battery pack can be charged by either 1) removing the pack from the control box housing and plugging it into the charger, or by 2) keeping the pack in the control box housing and plugging it into the charger.
- Battery pack powers only the height adjustable product
- If you are not regularly using your workstation with the battery pack, the battery should be placed on the charger and fully charged at least every 6 months. Otherwise your battery is susceptible to a deep discharge.
- If you plan on not using your workstation for 6 months or more, fully charge the battery pack and place it back into ship mode (ship mode is used for shipping and storage purposes it ensures low power consumption). Once fully charged and in ship mode, the battery pack can be stored for up to 2 years on the shelf. Once you're ready to activate the battery pack again, plug it into the charger for a few seconds.

The Battery Pack is compatible with the following electric height adjustable products*:

- Elegante XT
- Elegante XT Conference
- Eficiente LT
- Eficiente LT Flip Marker Board
- Bonita ET
- Samara
- Victory Conference
- Presidente Executive
- Presidente Reception





Battery pack only



Control box housing only



Battery pack inserted into control box housing