

LIGHTING INSTRUCTIONS

- Press button 1x to activate flashlight (top light)
- Slide up to activate work light
- Press 1x to activate red light
- Press 2x to activate red flasher
- Slide down to turn OFF C·O·B



DIMMABLE BEAM

Each light mode is fully dimmable. Hold button for 1.5 seconds to activate dimming function. Flashlight, C·O·B White and Red are dimmable.

- Light will dim from 100% to 10% over 3 seconds.
- Light will flash quickly when it reaches 10% or 100% to indicate it has reached the lowest or highest light output
- Release button at any time to achieve desired brightness.
- Light will continue to dim/brighten between 100% and 10% until button is released.

MEMORY POWER SETTING

SLYDE+ is equipped with memory settings for each light mode. To program memory settings, start in the OFF position. Flashlight, C·O·B White and Red have this feature.

- Double-tap the button to activate Memory Power Setting. Flashlight (top) will activate.
- Follow Dimming Instructions to adjust light to desired brightness.
- Press button again to move to next setting. Light will cycle through each light mode sequentially.
- Set each light mode at desired brightness level.
- If 100% brightness is desired amongst light modes, simply press button to move to the next mode.
- Press again to turn OFF.

To reprogram, simply repeat the previous steps.

DIRECT-TO-RED

Press and hold the button while opening the C·O·B section to activate RED directly. Press button again to cycle through remaining C·O·B light modes.