NEBO° **ESSENTIALS** TRIO



DAVINCI® 3500

The DAVINCI 3500 features a high-powered 3500 lumen LED, 3x adjustable zoom and a rechargeable power bank.

MODES	LUMENS	HOURS	METERS
HIGH	3500	2	131
MEDIUM	700	5	65
LOW	70	20	32
STROBE	3500	2	131

4 Light Modes • Waterproof (IP67) • 3x Adjustable Zoom Power Bank • Anodized Aircraft-Grade Aluminum



mode.

MODE SELECT DIAL

Twist to select High,

Medium, Low and Strobe



3X ZOOM

Twist to adjust the light beam from spot light to flood light.



Battery Indicator Light (located behind power button):

Red = Low Battery Blue = Fully Charged

To charge your phone or other USB device, simply unscrew the base and plug it into the USB port.



INSPECTOR™ 500+

This 500 lumen, USB rechargeable pen light features a unique hidden Area Light. Flex Power allows for the use of 2x AAA batteries (not included).

8 Light Modes • Water resistant (IPX7) • Smart Power Control • Direct-to-Low • Anodized Aircraft-Grade Aluminum

	MODES	LUMENS	RUN TIME	METERS
ery	TURBO	500	30s	142
ä₩	HIGH	250	3.5h	98
E 8	LOW	25	8h	31
ᇫ	STROBE	250	2.5h	98

Sa	MODES	LUMENS	RUN TIME	METERS	
# #	TURBO	140	30s	80	
LIGHT Batteri	HIGH	70	1h	57	
₽₹	LOW	7	12h	18	
SX AAA	STROBE	70	1h	57	

	MODES	LUMENS	RUN TIME	METERS
LIGHT attery	TURBO	400	30s	16
	HIGH	200	3.5h	11
E E	LOW	20	8h	6
AR∃	STROBE	200	2.5h	11

. se	MODES	LUMENS	RUN TIME	METERS
토힐	TURBO	110	30s	8
LIG! Batt	HIGH	55	1h	6
¥₽	LOW	6	12h	4
ARE,	STROBE	55	1h	6

OPERATION

Power button cycles through light modes when pressed. High > Low. Double-tap button for **Strobe** mode. When the unit is Off, press and hold the power button to go Direct-To-Low. When the unit is On, press and hold the



AREA LIGHT To deploy the Area Light, pull the head away from the body.



RECHARGEABLE

To access the charging port, hold the body and rotate the collar clockwise down/away from the lens. Insert the USB cable into the charging port.

CHARGE INDICATOR

This product includes a "Charge Status" LED indicator during charging (located by the charge

- When plugged in and the light is red, the battery is charging.
- When plugged in and the light turns solid blue, the battery level is at 100%.




FLEX POWER

This unit can also be powered by two AAA batteries.

- Unscrew the battery cap.
- Remove the rechargeable batteries.
- Insert two AAA batteries positive (+) side
- Reinstall the battery cap.





MYCRO HEADLAMP

The rechargeable MYCRO Headlamp & Cap Light features a 400 lumen Turbo Mode, 5 additional light modes, 135º adjustable tilt and a USB to Micro USB charging cable.



TURBO MODE: press & hold button while ON DIRECT-TO-RED: press & hold button while OFF

400

150

50

15

1


LOW

GREEN RED




MODE RECALL

Once the light has been ON for 8 seconds, the next button push with turn the light OFF. After the MYCRO has been turned OFF, the next button push will activate the last used mode.



VERSATILE CLIP

Provides 135º adjustable tilt and use as a cap light when the head strap unit is removed. To remove, pull Tab upwards to detach from Tab Slot and pull unit away from the MYCRO. To reattach, simply push back into place.



USB RECHARGEABLE

To charge, plug the USB end into a power source and plug the Micro USB end into the MYCRO.

The battery indicator LED will glow red while charging and green when fully charged.





This product is guaranteed against all defects in workmanship and materials for the original owner for one year from the date of purchase.

LUMENS RUNTIME METERS

30s

1h

2h

5h

10h

10h

80

50

10

For more information, detailed video instructions, and warranty registration, visit NEBOLIGHTS.com.

Alliance Consumer Group 700 Henrietta Creek Road Roanoke, TX 76262 800.255.6061

Made in China