

Register and Save!

All warranty registrations will receive a 10% discount coupon code on any NEBO online retail purchase.

Register and Win!

Each month, one lucky winner will be drawn from all new warranty registrations and will win the newest NEBO light.

NEBO One Year Warranty

All NEBO products are guaranteed against all defects in workmanship and materials for one year from the date of purchase.

Register your warranty

www.nebotools.com/warranty



QUALITY GUARANTEE

This product is guaranteed against all defects in workmanship and materials for the original owner for one year from the date of purchase. Damage to or failure of the flashlight or any component thereof due to alteration, misuse, battery leakage or lack of maintenance will void any and all guarantees. Damage by leakage of batteries should be taken up with the manufacturer of the battery using their damage claim instructions. For any additional information call 1-800-255-8061.

All copyrighted and v materials, including, without limitation, the logo, design, text, graphics, pictures, copywriting and the selection and arrangement ("Materials") thereof are ALL RIGHTS RESERVED Copyright © 2020 Alliance Sports Group L.P.

INTERNATIONAL PATENTS PENDING

WARNING

AVOID EYE INJURY-Do not stare directly into beam or shine it directly into anyone's face. Doing so for more than a few seconds could cause retinal damage. Do not allow children to use LED lights unless under the supervision of an adult.

NEBO



TORCHY

1000 LUMEN RECHARGEABLE



user manual
item #6878

LIGHTING INSTRUCTIONS

The TORCHY features 5 light modes controlled by the side-positioned ON/OFF button.

LIGHT MODES

- Press 1x for HIGH
- Press 2x for MEDIUM
- Press 3x for LOW
- Press again to turn OFF
- Double press for STROBE



REMOVABLE CLIP

The TORCHY is equipped with a steel belt/pocket clip. To remove, simply pull the clip away from the TORCHY.



MODE RECALL FEATURE

Mode Recall Feature remembers the last used light mode. After the TORCHY is ON for more than 8 seconds, and then turned OFF, the next press of the button will automatically recall the last used light mode. The normal light mode sequence will continue upon the next press of the button.

CHARGING INSTRUCTIONS

The TORCHY has a battery status LED in the button, which indicates power level.

- Button will glow **RED** when battery is less than 25%.
- Button will glow **BLUE** when battery is over 25%.

A Mag-Cable™ magnetic USB to USB charging cable is included to charge the TORCHY.

- Charging indicator will glow **RED** when charging.
- Charging indicator will glow **BLUE** when fully charged.



NOTE: Before using the TORCHY, it is best to fully charge the unit. (TORCHY should fully recharge in less than 2 hours)



Smart Power Control reduces the instantaneous light output by gradually increasing the brightness when turning the light ON or transitioning between light modes. This reduces power consumption, helps expand battery life and allows the user's eyesight to adjust easier, as the light intensifies.



HIGH
500 LUMENS
• 1 Hour
• 100 Meters



MEDIUM
200 LUMENS
• 1.75 Hours
• 60 Meters



LOW
50 LUMENS
• 6 Hours
• 30 Meters



STROBE
500 LUMENS
• 1 Hour
• 100 Meters



TURBO MODE
1000 LUMENS
• 30 Seconds
• 130 Meters