

# INSTALLATION INSTRUCTIONS

## AT Series--THERMOSTAT 74T12

The AT Series of 3/4" (19mm) bimetal disc temperature controls offers proven reliability in a versatile, cost-effective design. Can handle loads up to 25 amps at 240VAC. Adjustable temperature setting.



**Disconnect power before servicing equipment.**

1. Disconnect power.
2. Remove wires from thermostat.
3. Remove screws from thermostat. Keep screws for replacement thermostat.
4. Before installing new thermostat, check to ensure the wire connectors are not damaged or loose.
5. Set thermostat to desired temperature.
6. Attach thermostat with screws.
7. Reconnect wires to the thermostat.
8. Reconnect power.

**800.333.9125 - techsupport@supco.com - www.supco.com**