

NEBO[®]

**3-IN-1
FLASHLIGHT**



USER MANUAL
NEB-WLT-0028

USER INSTRUCTIONS

- Press button 1x to activate FLASHLIGHT
- Press 2x to activate WORKLIGHT
- Press 3x to activate LANTERN
- Press again to turn OFF

(Note: Leave any mode On for 5 seconds or longer and your next press of the button turns light OFF)

SWITCHING BATTERY

1. To open battery compartment, unscrew (counter-clockwise) the end cap where the magnetic base is located.
2. Remove the old AAA batteries. Insert 4 new AAA alkaline batteries as indicated in the markings on the product.
3. Reattach end cap by turning clockwise.

LIGHT MODES

FLASHLIGHT 4 AAA Batteries (included):	HIGH 400 LUMENS	LOW 40 LUMENS
	• 2 Hours • 89 Meters	• 20 Hours • 28 Meters

LANTERN 4 AAA Batteries (included):	HIGH 200 LUMENS	LOW 20 LUMENS
	• 2 Hours • 13 Meters	• 13 Hours • 4 Meters

WORK LIGHT 4 AAA Batteries (included):	HIGH 75 LUMENS	LOW 10 LUMENS
	• 10 Hours • 11 Meters	• 26 Hours • 4 Meters

ADJUSTABLE ZOOM

- Turn the head counter-clockwise to go from flood light to spot light.
- Turn the head clockwise to go from spot light to flood light.

DIMMABLE BEAM

Each light mode is fully dimmable. Hold button for 1.5 seconds to activate dimming function.

- Light will dim from 100% to 10% over 3 seconds.
- Light will flash quickly when it reaches 10% or 100% to indicate it has reached the lowest or highest light output.
- Release button at any time to achieve desired brightness.
- Light will continue to dim/brighten between 100% and 10% until button is released.

This light functions with:

(4) AAA Alkaline



QUALITY GUARANTEE
This product is guaranteed against all defects in workmanship and materials for the original owner for one year from the date of purchase. Damage to or failure of the flashlight or any component thereof due to alteration, misuse, battery leakage or lack of maintenance will void any and all guarantees. Damage by leakage of batteries should be taken up with the manufacturer of the battery using their damage claim instructions. For any additional information call 1-800-235-0061.

All copyrighted and copyrightable materials, including, without limitation, the logo, design, text, graphics, pictures, copywriting and the selection and arrangement ("Materials") thereof are ALL RIGHTS RESERVED Copyright © 2020 Alliance Sports Group L.P.

WARNING
AVOID EYE INJURY: Do not stare directly into beam or shine it directly into anyone's face. Staring for more than a few seconds could cause retinal damage. Do not allow children to use LED lights unless under the supervision of an adult.

CAUTION
Do not mix old and new batteries. Do not mix alkaline, standard (carbon/zinc), or rechargeable (nickel or hybrid) batteries. Do not use rechargeable or reusable alkaline batteries. Dispose of all batteries properly.