

Before operation, open the battery compartment and remove the round battery spacer disc.



OPERATION

Fully press & release power button to turn the unit off and on. Press halfway to cycle through light modes:

High > Medium > Low > Strobe > Beacon

If the unit is powered OFF (full press) and then back ON within 8 seconds, the mode sequence is resumed.

After 8 seconds of being OFF, the next activation will resume from High regardless of the previous mode.



Twist the head to narrow or widen the light beam.

10X ZOOM



This unit is powered by 9x alkaline AA batteries.


BATTERY

DO NOT mix old and new batteries. **DO NOT** mix alkaline, standard (carbon-zinc), or

rechargeable (Ni-Cad, Ni-MH, etc.) batteries.

WARNING!

Unit can become hot while in use. Keep the crown away from surfaces until the unit cools.



PRODUCT GUARANTEE

If you experience a problem, please do not return to your local store. Contact our Customer Service team at **800-255-6061** or www.nebotools.com/contact

For more information, detailed video instructions, and warranty registration, visit

NEBOLIGHTS.com