




# PLASMA LIGHTER XR



## OPERATION

Each press of the power button will activate the lighter. If held continuously, the lighter will be interrupted after 6 seconds. To reactivate the lighter, release the power button and press it again.

## LED INDICATOR

Located next to the charging port, it indicates:  
Battery Low - Flashing  
Charging - Solid  
Fully Charged - Turns Off

## SAFETY NOTICE

Continuously reactivating the lighter can cause the lighter head to get very hot. Please allow the lighter head to cool before touching it.

**EXTEND** - Grab the sides of the lighter head and pull up.

**COLLAPSE** - Ensure lighter head is cool. Grab the lighter head and press it back into the housing of the lighter.

**TRUE.ACGBRANDS.COM**

## 1 YEAR PRODUCT GUARANTEE

If you experience a problem, please do not return to your local store. Contact our Customer Service team at 800-255-6061 or [true.acgbrands.com/contact](http://true.acgbrands.com/contact).