

# NEBO<sup>®</sup>

## SLYDE KING™ 4K



The Slyde King™ 4K combines a high-powered 4000 lumen flashlight, 1000 lumen work light and a strong magnetic base for hands-free use.



4X ADJUSTABLE ZOOM



WATERPROOF  
1 METER · 30 MIN



AIRCRAFT GRADE ALUMINUM



MAGNETIC BASE



### USB-C RECHARGEABLE

Fully recharge in as little as 4 hours.





### IMPORTANT: BEFORE USE

This work light comes with Demo Mode activated. Charge the light to deactivate.

USB-C

USB-A



### CHARGING INSTRUCTIONS

Insert the USB-C end of the included charging cable into the USB-C port on the flashlight. Next, insert the USB-A end of the charging cable into a power source with a USB-A port.

### WHEN CHARGING

**N** The power button light serves as the charging status indicator.



Solid Green: Battery is charged



Pulsing Green: Battery is charging

### BATTERY LEVEL INDICATOR

**N** The power button light serves as the battery level indicator while the product is in use (any mode).



Steady Orange: Battery more than 25%




Pulsing Orange: Battery less than 25%



### FLASHLIGHT

Light up the night with 400 to 4000 lumens to see near or far.



### FLASHLIGHT OPERATION

#### POWER SELECT

Press the power button to turn on light. Press againto turn off light.

#### BRIGHTNESS/DIMMING

Lights have continuous dimming and brightening cycling with memory.

When ON, press and hold power button to activate dimming; release to set desired brightness. Double-tap from off to activate dimmed flashlight mode.

#### 4X ZOOM

Twist the head of the light to adjust the light beam from flood light to spot light.



### FLASHLIGHT OPERATION

#### POWER SELECT

Press the power button to turn on light. Press againto turn off light.

#### BRIGHTNESS/DIMMING

Lights have continuous dimming and brightening cycling with memory.

When ON, press and hold power button to activate dimming; release to set desired brightness. Double-tap from off to activate dimmed flashlight mode.

#### 4X ZOOM

Twist the head of the light to adjust the light beam from flood light to spot light.



### WORK LIGHT

Dimmable control between 100 to 1000 lumens.



### WORK LIGHT

Dimmable control between 100 to 1000 lumens.



Preserve your night vision with direct-to-red or switch to the hazard flasher for emergencies.


### WORK LIGHT

Dimmable control between 100 to 1000 lumens.



### RED MODE

Preserve your night vision with direct-to-red or switch to the hazard flasher for emergencies.



### INNOVATIVE

Slide-to-reveal design.



### WORK LIGHT OPERATION

#### MODE SELECT

Slide open to activate the work light. Press and release power button to switch between White, Red, and Flash modes.

#### DIRECT-TO-RED

Press and hold power button while sliding the work light open.

#### BRIGHTNESS/DIMMING

Lights have continuous dimming and brightening cycling with memory.

When ON, press and hold power button to activate dimming; release to set desired brightness. Double-tap to activate dimmed work light mode.

MODES	OUTPUT (Lumens)	RUN TIME (Hours)	BEAM DISTANCE (Meters/Yards)
FLASHLIGHT HIGH	4000	1	350 / 382
FLASHLIGHT LOW*	400	6	100 / 109
WORK LIGHT HIGH	1000	4	35 / 38
WORK LIGHT LOW*	100	24	10 / 10
RED LIGHT HIGH	40	6	-
RED LIGHT LOW*	-	35	-
RED STROBE	-	-	-

\*Low modes are activated via the dimming function

### PRODUCT GUARANTEE



If you experience a problem, please do not return to your local store. Contact our Customer Service team at 800-255-6061 or [NEBOLIGHTS.com](http://NEBOLIGHTS.com)

For more information, detailed video instructions, and warranty registration, visit [NEBOLIGHTS.com](http://NEBOLIGHTS.com)