

INSTALLATION INSTRUCTIONS

STC5333--THERMAL CUTOUT 15 AMP, 333°F

Rated for continuous operating currents up to 10 amps @ 250VAC/15 amps @ 120VAC, or 5 amps @ 24VDC

Designed for over-temperature protection.

1. Disconnect power.
2. Remove screw holding ceramic body. (Keep screw)
3. Remove wires from thermal cut out.
4. Before installing new thermal cutout, check to ensure the wire connectors are not damaged or loose.
5. Reconnect wires to the thermal cutout.
6. Attach ceramic body with screw.
7. Reconnect power.



Disconnect power before servicing equipment.

800.333.9125 - techsupport@supco.com - www.supco.com