

NEBO®

FRANKLIN™ BLOOD TRACKER

Before operation, open the battery compartment and remove the round battery spacer disc.



OPERATION

Press & release power button to turn the unit off and on and cycle through light modes:

White > Blue > Red > Blood Tracker > Off

White and **Blood Tracker** modes feature dimming with memory. To activate dimming, press & hold the power button. Double-tap to add the setting to memory.

If there is no button activity after 8 seconds, the next press will turn the unit Off.

From **Off**, press & hold the power button to directly enter **Blood Tracker** mode.



SWIVEL

A simple twist will swivel the head 90°.



BATTERY

This unit is powered by 4 AAA batteries. Do not mix old and new batteries. Do not mix alkaline, standard (Carbon-zinc), or rechargeable (Ni-Cd, Ni-Mh, etc) batteries.

To replace batteries, unscrew the tail cap and insert new batteries in the direction as indicated on the battery tray.

PRODUCT GUARANTEE



If you experience a problem, please do not return to your local store. Contact our Customer Service team at **800-255-6061** or www.nebolights.com/contact

For more information, detailed video instructions, and warranty registration, visit NEBOLIGHTS.com