

Installation Guide For Clear Blue[®] PCO System

1. Secure this template on the duct in the appropriate location
2. Drill and cut out where indicated
3. Mount the Clear Blue[®] PCO System using the supplied black screws. **DO NOT USE THE SCREWS SUPPLIED WITH THE Clear Blue[®] Master**



Drill



Cut out



Air Flow

WARNING

Use a vacuum or forced air to clean the PCO module. Do not submerge in water.

WARNING

Before installing or performing maintenance or service on the purifier, **DISCONNECT** from main power. Electrical shock can cause injury or death.

WARNING

Never expose eyes or skin to ultraviolet light from any source. The Purifier **MUST** be **DISCONNECTED** from power source before performing maintenance or service. Personal injury may result.

WARNING

Do not touch Lamp glass without gloves. Reduced performance of Lamp may result. Clean Lamp after handling with isopropyl alcohol.

WARNING

The UV Lamp contains a small quantity of mercury. If a Lamp breaks, clean and dispose of with care.

WARNING

Use only specified replacement Lamps with your Purifier. Use of an incorrect Lamp can result in damage to the Purifier and/or Lamp. Lamp part #: UUVS-LP160T5

