





Tevita Casegoods Dual Credenza Assembly Instructions



Warranty: raproducts.com/resources/warranty


Tools Required for Assembly

- A. Power Driver with Adjustable Torque
- B. #2 Square Head Driver Bit






Hardware and Tools Included for Assembly *(may have extra)*

- C. 4mm Ball End Screwdriver
- D. 5/8" Washer Head Wood Screw x32






Parts

- E. Feet x8
- F. Joiner Plate x2
- G. Bottom Panel x2
- H. Top Panel x1
- I. Left Panel x2
- J. Right Panel x2
- K. Back Panel x2



Parts (continued)

- I. Left Panel x2
- J. Right Panel x2
- K. Back Panel x2



Step 1

- Place the top panel (H) on a flat, protected surface with the pilot holes facing up.
- Take one left panel (I) and align the cabineo connectors with the pre-drilled pilot holes on the top panel (H).
- Using the 4mm ball end screwdriver (C), screw the cabineo connectors to secure it to the top panel (H). See Figure A below to see how to use the 4mm ball end screwdriver (C).








Figure A





Step 2

- Take one back panel (K) and align the cabineo connectors with the pre-drilled pilot holes on the top panel (H) and the left panel (I).
- Using the 4mm ball end screwdriver (C), screw the cabineo connectors on the back panel (K) to secure it to the top panel (H) and the left panel (I).





Step 3

- Take one right panel (J) and align the cabineo connectors with the pre-drilled pilot holes on the top panel (H) and the back panel (K).
- Using the 4mm ball end screwdriver (C), screw the cabineo connectors on the right panel (J) to secure it to the top panel (H) and the back panel (K).





Step 4

- Take the second left panel (I) and align the cabineo connectors with the pre-drilled pilot holes on the top panel (H).
- Using the 4mm ball end screwdriver (C), screw the cabineo connectors on the left panel (I) to secure it to the top panel (H).





Step 5

- Take the second back panel (K) and align the cabineo connectors with the pre-drilled pilot holes on the top panel (H) and the second left panel (I).
- Using the 4mm ball end screwdriver (C), screw the cabineo connectors on the back panel (K) to secure it to the top panel (H) and the second left panel (I).





Step 6

- Take the second right panel (J) and align the cabineo connectors with the pre-drilled pilot holes on the top panel (H) and the second back panel (K).
- Using the 4mm ball end screwdriver (C), screw the cabineo connectors on the right panel (J) to secure it to the top panel (H) and the back panel (K).





Step 7

- Place one bottom panel (G) onto the back and side panels as shown in the image. Align the pre-drilled pilot holes on the bottom panel (G) to the cabineo connectors on the back and side panels.
- The side of the bottom panel (G) with more pilot holes should be facing upwards.
- Using the 4mm ball end screwdriver (C), screw the six (6) cabineo connectors on the back and side panels to secure them to the bottom panel (G).





Step 8

- Place the second bottom panel (G) onto the other set of back and side panels as shown in the image. Align the pre-drilled pilot holes on the bottom panel (G) to the cabineo connectors on the back and side panels.
- The side of the bottom panel (G) with more pilot holes should be facing upwards.
- Using the 4mm ball end screwdriver (C), screw the six (6) cabineo connectors on the back and side panels to secure them to the bottom panel (G).



Step 9

- Place the two joiner plates (F) onto the two bottom panels (G) and align with the pre-drilled pilot holes as shown in the image.
- Secure the joiner plates (F) to the bottom panels (G) using the washer head wood screws (D).



Step 10

- Align four (4) feet (E) with the pre-drilled pilot holes on corners of each bottom panel (G).
- Secure the feet to the bottom panel using four (4) washer head wood screws per foot.
- Flip the credenza right side up.

NOTE: Skip this step if adding the caster kit. Please refer to the instructions provided with the caster kit for install.

