





Heavy Duty Dog Barrier for Wide Gap Fence Installation Instructions

HARDWARE PARTS

A	B	B	C
<p>QTY: 1 roll</p>  <p>Welded Wire Dog Fence-14 ga. galvanized steel core; 12 ga after Black PVC-Coating, 2" x 2" Mesh</p> <p>(See packing slip for SKU)</p>	<p>Hardware for METAL</p> <p>QTY: 1 pk per 100 ft</p>  <p>8" High Strength Nylon Self-Locking Ties – 100pk</p> <p>SKU: DE2854</p>	<p>Hardware for WOOD</p> <p>QTY: 1 pk</p>  <p>1/8" Aluminum Fence Wire Clips w/ Wood Screws – 100pk</p> <p>SKU: DE2854</p>	<p>QTY: 1 pk</p>  <p>12" Kinked Ground Stakes</p> <p>SKU: DE2878-30</p>
<p align="center">Recommended Tools (not included)</p> <p align="center">Cutter Puller Tool for Self-Locking Ties, SKU: DE2864</p> <p align="center">Power Drill with Phillips Bit</p>			


Heavy Duty Dog Barrier for Wide Gap Fence Installation Instructions

1. On the **INSIDE** of your fence line, unroll your **FENCE MESH (A)** clip the **FENCE MESH (A)** between the **FENCE CLIPS (B)** and secure the **CLIPS (B)** to your fence with provided screws. We recommend attaching the **CLIPS (B)** to main vertical posts so that there is **at least 6 inches** of flare at the bottom of the fence line. Secure the flared bottom using a **KINKED STAKE (C) every 3-4'**.

Note: Use remaining **CLIPS (B)** as needed to tightly secure the fence.

WOOD

1.



Every 3-4'

METAL

1. On the **INSIDE** of your fence line, unroll your **FENCE MESH (A)** and attach the **FENCE MESH (A)** to metal posts using **SELF-LOCKING TIES (B)**. We recommend attaching **SELF LOCKING TIES (B)** to posts so that there is **at least 6 inches** of flare at the bottom of the fence line. Secure the flared bottom using a **KINKED STAKE (C)** every 3-4' apart.

Note: Use **one (1) SELF-LOCKING TIE (B)** every 1' along the length of the post and **every 5'** apart.

1.

