



ergonomic products

K&A MANUFACTURING

6703 ZINSER ST., SCHOFIELD, WI 54476
PHONE: 800.298.4351 FAX: 866.882.9475
www.raproducts.com

VERSION DATED: 1/22/14

TOOLS REQUIRED FOR ASSEMBLY:

- CORDLESS DRILL
- #2 SQUARE HEAD DRIVER BIT
- NEEDLE NOSE PLIERS
- THIN FLAT BLADE SCREWDRIVER




NewHeights SERIES 4 XT MOTOR REPLACEMENT INSTRUCTIONS:

WHEN WORKING ON THE LEG ASSEMBLY, DO NOT ALLOW IT TO STAND UNSUPPORTED. IT COULD TIP RESULTING IN A CRACKED GEAR CASING.

STEP 1: WITH A THIN FLAT BLADED SCREWDRIVER, START LOOSENING THE (2) PUSH-ON RETAINER CLIPS HOLDING THE GEAR CASING IN PLACE. REMOVE THEM THE REST OF THE WAY USING A NEEDLE NOSE PLIERS.

STEP 2: REMOVE THE DAMAGED MOTOR AND DISCARD IT AND THE RETAINER CLIPS. PLACE THE NEW MOTOR IN THE MOTOR BOX ALIGNING THE PINS WITH THE HOLES IN THE GEAR CASING. INSTALL THE MOTOR WITH THE WIRE FACING DOWN. ROUT THE MOTOR WIRE OUT THE GROOVE TOWARD THE BACK OF THE MOTOR BOX.

STEP 3: PUSH THE NEW RETAINER CLIPS ONTO THE PINS AS FAR AS THEY WILL GO. PROCEED WITH THE ASSEMBLY OF THE WORKSTATION.



THE MOTOR WIRES EXIT THE MOTOR BOXES TOWARD THE BACKS OF THE LEG ASSEMBLIES